

1.0 Overview

The new CPU-95 Display (791908-1) module incorporates data logging and a new half-duplex RS485 port that is Modbus RTU compliant.

2.0 Modbus RTU

2.1 Modbus RTU Overview

The CPU-95 Display Module follows the Modicon Modbus RTU standard.

2.2 Aux Port Setup

The Modbus configuration is accessed through the "AUX PORT SETUP" menu. It is found in the setup menu after the "RUN TEST MODE" menu.

AUX PORT SETUP
Next Esc Enter

To enter the auxiliary port setup menus press "ENTER".

To continue to the datalog setup menu press "NEXT".

To exit press "ESC".

2.3 Aux Port Node Id

AUX PORT NODE ID
1 ↑↓

Valid node id's are from 1 to 255.

To change the node id use the "↑" & "↓" keys.

To continue to the aux port mode menu press "NEXT".

To exit press "ESC".

2.4 Aux Port Mode

AUX PORT MODE ↑↓
ModBudRTU96008n1

To change the mode use the "↑" & "↓" keys.

To return to the aux port node id menu press "NEXT".

To exit press "ESC".

The supported baud rates are:

300, 600, 1200, 2400, 4800, 9600, 19.2k, 38.4k.

The supported parity(s) are:

(n) none, (o) odd, & (e) even.

The only supported data bits is 8 with 1 stop bit.

2.5 Aux Port Diagnostic

By pressing the "DIAG" key on either the "AUX PORT MODE", "AUX PORT NODE ID", or the "AUX PORT SETUP" menu, the "MODBUS ERROR" menu will appear

MODBUS ERROR
NONE

To go to the "AUX PORT SETUP" menu press "NEXT".

To reset the error indicator back to none press "RESET".

To exit press "ESC".

This menu will display the last error reported by the modbus interpreter. The list of errors that are flagged are:

"CRC" the checksum of the incoming data was invalid.

"RCV BUF OVF" the incoming data was greater than 256 bytes.

"UKN FN

"INVALID ADDRESS" the received data contained an invalid address field.

"INVALID DATA LEN" the received data contained an invalid data length field.

"INVALID DATA" the received data contained an invalid data value.

t is currently busy.

"NONE" no errors encountered since last reset.

2.6 Modbus Special Functions

2.6.1 Identification (17):

Query:

NN 17 CRC CRC

NN = node number, 17 = ID function code, CRC CRC = two byte Modbus RTU CRC.

Response:

NN 17 18 00 RC VM Vm M M / D D / Y Y D S P - 9 5 CRC
CRC

NN

to follow, RC = Run Condition, VM = Version Major, Vm = Version minor, an ASCII string that is the firmware date, DSP-95 ASCII string indicating the CPU-95 display module, & CRC CRC = two byte Modbus RTU CRC.

RC (run condition) is set to 0 anytime the display loses contact

operation.

VM & Vm are a two digit firmware version (ie 1.0).

2.6.2 Remote Operator Interface (ROI) (100):

Query:

NN = node number, 100 = ROI function code, KP is the single byte "Key Press" from the table below, CRC CRC = two byte Modbus RTU CRC.

"Key Press" Table

00 = NONE (returns current display)

01 = "↑"

03 = "MAN"

05 = "↓"

07 = "TIMING"

09 = "ESC"

11 = "F2"

13 = "ENTER"

15 = "F4"

02 = "DIAG"

04 = "AUTO"

06 = "NEXT"

08 = "SETUP"

10 = "RESET"

12 = "F1"

14 = "ALARM ACK"

16 = "F3"

Response:

NN 100 36 (16bytes 1st line of display) CR LF (16 bytes 2nd line) CR LF CRC CRC

NN = node number, 100 = ROI function code, 36 = number of bytes to follow, CR = Carriage Return, LF = Linefeed, 2 16 byte ASCII blocks that is the display, CRC CRC = two byte Modbus RTU CRC

2.6.3 Read Input Status Label (102):

Query:

NN 102 ADH ADL CRC CRC

NN = node number, 102 = function code, ADH:ADL = Two byte address of desired input status (1-512), CRC CRC = two byte Modbus RTU CRC.

Response:

NN 102 30 ASCII STRING CRC CRC

NN follow, ASCII STRING = returned label string for the requested input status, CRC CRC = two byte Modbus RTU CRC.

2.6.4 Read Input Register Label (104):

Query:

NN 104 ADH ADL CRC CRC

NN = node number, 102 = function code, ADH:ADL = Two byte address of desired input register (1-256), CRC CRC = two byte Modbus RTU CRC.

Response:

NN 104 30 A S C I I S T R I N G C R C C R C

NN follow, ASCIISTRING = returned label string for the requested input register, CRC CRC = two byte Modbus RTU CRC.

2.6.5 Read Datalog (130):

Query:

NN 130 DLN CRC CRC

NN = node number, 130 = function code, DLN = datalog number from 0 to 100, CRC CRC = two byte Modbus RTU CRC.

Response:

NN 130 250 D A T A L O G C R C C R C

NN follow, DATALOG = returned datalog, CRC CRC = two byte Modbus RTU CRC.

2.6.6 Read ASCII Capture (230):

Query:

NN 230 DLN CRC CRC

NN = node number, 130 = function code, DLN = datalog number from 0 to 100, CRC CRC = two byte Modbus RTU CRC.

Response:

NN 130 90 A S C I I S T R I N G C R C C R C

NN follow, ASCIISTRING = returned ASCII Capture, CRC CRC = two byte Modbus RTU CRC.

2.7 Modbus Register List

10001	= "IGN SHUTDOWN FLAG	"
10002	= "IGN WARNING FLAG	"
10003	= "IGN FAULT FLAG	"
10004	= "IGN FIRED FLAG	"
10005	= "IGN ALARM OUTPUT ACTIVATED	"
10006	= "IGN FIRING FLAG	"
10007	= "IGN PICKUPS OK	"
10008	= "IGN ENGINE ROTATING	"
10009	= "spare	"
10010	= "spare	"
10011	= "spare	"
10012	= "ONE STEP ACTIVE NOW	"
10013	= "ENERGY LEVEL E1 NOW	"
10014	= "ENERGY LEVEL E2 NOW	"
10015	= "ENERGY LEVEL E3 NOW	"
10016	= "MULTI STRIKE NOW	"
10017	= "FAULT NO GEAR TOOTH SIGNAL	"
10018	= "FAULT NO MAGNETIC RESET SIGNAL"	"
10019	= "FAULT NO CYCLE RESET SIGNAL	"
10020	= "FAULT WRONG NUMBER OF TEETH	"
10021	= "FAULT OVERSPEED SHUTDOWN	"
10022	= "spare	"
10023	= "spare	"
10024	= "FAULT FIRMWARE CHECKSUM ERR	"
10025	= "spare	"
10026	= "spare	"
10027	= "spare	"
10028	= "spare	"
10029	= "WARN 4-20 LOOP OUT OF RANGE	"
10030	= "spare	"
10031	= "WARN EEPROM CHECKSUM FAIL	"
10032	= "WARN FAIL DETECT DISP MODULE	"
10033	= "spare	"
10034	= "WARN HI VOLTAGE	"
10035	= "WARN NO SECONDARY SPK	"
10036	= "WARN LO FROM ENGINE	"
10037	= "WARN HI FROM ENGINE	"
10038	= "WARN LO VOLTAGE	"
10039	= "WARN PRIMARY SHORT	"
10040	= "WARN PRIMARY OPEN	"
10041	= "PROTECTION ENABLED	EEPROM"
10042	= "SERIAL RETARD ENABLED	EEPROM"

10043 ="RPM RETARD MAP ENABLED EEPROM"
10044 ="4-20ma RET MAP ENABLED EEPROM"
10045 ="BASE ENERGY E1 SELECT EEPROM"
10046 ="BASE ENERGY E2 SELECT EEPROM"
10047 ="BASE ENERGY E3 SELECT EEPROM"
10048 ="MULTI-STRIKE SELECT EEPROM"
10049 ="FIRE CONFIRM OUTPUT 1 = FIRING"
10050 ="SHUTDOWN OUTPUT 0 = SHUTDOWN"
10051 ="ALARM OUTPUT 0 = ALARM"
10052 ="spare "
10053 ="TRANSCODER 0=4X 1=8X"
10054 ="SKIP CONTROL (internal) "
10055 ="CMDPAGE2 (internal) "
10056 ="TWO CYCLE "
10057 ="spare "
10058 ="spare "
10059 ="spare "
10060 ="CHKPAGE2 (internal) "
10061 ="MISC INPUT "
10062 ="MISC REMOTE INPUT "
10063 ="spare "
10064 ="spare "
10065 ="20 OUTPUT MODULE "
10066 ="18 OUTPUT MODULE "
10067 ="DUAL CAPACITOR MODULE "
10068 ="WITH FILTER MODULE "
10069 ="spare "
10070 ="spare "
10071 ="spare "
10072 ="spare "
10073 ="MISC. 0=USE ONESTEP "
10074 ="MISC. 0=FIRE MAXENERGY "
10075 ="MISC. 0=FIRE MULTISTRIKE "
10076 ="spare "
10077 ="RPM < 200 USE ONESTEP "
10078 ="RPM < 200 FIRE MAX ENERGY "
10079 ="RPM < 200 FIRE MULTI "
10080 ="spare "
10081 ="spare "
10082 ="spare "
10083 ="spare "
10084 ="spare "
10085 ="WITH OFFSET "

10086 ="TEST DENY (internal)"
10087 ="TEST ACT (internal)"
10088 ="TEST REQ (internal)"
10089 ="spare (A or A1)"
10090 ="WARN HI VOLTAGE (A or A1)"
10091 ="WARN NO SECONDARY SPK(A or A1)"
10092 ="WARN LO FROM ENGINE (A or A1)"
10093 ="WARN HI FROM ENGINE (A or A1)"
10094 ="WARN LO VOLTAGE (A or A1)"
10095 ="WARN SHORTED PRIMARY (A or A1)"
10096 ="WARN OPEN PRIMARY (A or A1)"
10097 ="spare (B or A2)"
10098 ="WARN HI VOLTAGE (B or A2)"
10099 ="WARN NO SECONDARY SPK(B or A2)"
10100 ="WARN LO FROM ENGINE (B or A2)"
10101 ="WARN HI FROM ENGINE (B or A2)"
10102 ="WARN LO VOLTAGE (B or A2)"
10103 ="WARN SHORTED PRIMARY (B or A2)"
10104 ="WARN OPEN PRIMARY (B or A2)"
10105 ="spare (C or B1)"
10106 ="WARN HI VOLTAGE (C or B1)"
10107 ="WARN NO SECONDARY SPK(C or B1)"
10108 ="WARN LO FROM ENGINE (C or B1)"
10109 ="WARN HI FROM ENGINE (C or B1)"
10110 ="WARN LO VOLTAGE (C or B1)"
10111 ="WARN SHORTED PRIMARY (C or B1)"
10112 ="WARN OPEN PRIMARY (C or B1)"
10113 ="spare (D or B2)"
10114 ="WARN HI VOLTAGE (D or B2)"
10115 ="WARN NO SECONDARY SPK(D or B2)"
10116 ="WARN LO FROM ENGINE (D or B2)"
10117 ="WARN HI FROM ENGINE (D or B2)"
10118 ="WARN LO VOLTAGE (D or B2)"
10119 ="WARN SHORTED PRIMARY (D or B2)"
10120 ="WARN OPEN PRIMARY (D or B2)"
10121 ="spare (E or C1)"
10122 ="WARN HI VOLTAGE (E or C1)"
10123 ="WARN NO SECONDARY SPK(E or C1)"
10124 ="WARN LO FROM ENGINE (E or C1)"
10125 ="WARN HI FROM ENGINE (E or C1)"
10126 ="WARN LO VOLTAGE (E or C1)"
10127 ="WARN SHORTED PRIMARY (E or C1)"
10128 ="WARN OPEN PRIMARY (E or C1)"

10129 ="spare (F or C2)"
10130 ="WARN HI VOLTAGE (F or C2)"
10131 ="WARN NO SECONDARY SPK(F or C2)"
10132 ="WARN LO FROM ENGINE (F or C2)"
10133 ="WARN HI FROM ENGINE (F or C2)"
10134 ="WARN LO VOLTAGE (F or C2)"
10135 ="WARN SHORTED PRIMARY (F or C2)"
10136 ="WARN OPEN PRIMARY (F or C2)"
10137 ="spare (K or D1)"
10138 ="WARN HI VOLTAGE (K or D1)"
10139 ="WARN NO SECONDARY SPK(K or D1)"
10140 ="WARN LO FROM ENGINE (K or D1)"
10141 ="WARN HI FROM ENGINE (K or D1)"
10142 ="WARN LO VOLTAGE (K or D1)"
10143 ="WARN SHORTED PRIMARY (K or D1)"
10144 ="WARN OPEN PRIMARY (K or D1)"
10145 ="spare (L or D2)"
10146 ="WARN HI VOLTAGE (L or D2)"
10147 ="WARN NO SECONDARY SPK(L or D2)"
10148 ="WARN LO FROM ENGINE (L or D2)"
10149 ="WARN HI FROM ENGINE (L or D2)"
10150 ="WARN LO VOLTAGE (L or D2)"
10151 ="WARN SHORTED PRIMARY (L or D2)"
10152 ="WARN OPEN PRIMARY (L or D2)"
10153 ="spare (M or E1)"
10154 ="WARN HI VOLTAGE (M or E1)"
10155 ="WARN NO SECONDARY SPK(M or E1)"
10156 ="WARN LO FROM ENGINE (M or E1)"
10157 ="WARN HI FROM ENGINE (M or E1)"
10158 ="WARN LO VOLTAGE (M or E1)"
10159 ="WARN SHORTED PRIMARY (M or E1)"
10160 ="WARN OPEN PRIMARY (M or E1)"
10161 ="spare (N or E2)"
10162 ="WARN HI VOLTAGE (N or E2)"
10163 ="WARN NO SECONDARY SPK(N or E2)"
10164 ="WARN LO FROM ENGINE (N or E2)"
10165 ="WARN HI FROM ENGINE (N or E2)"
10166 ="WARN LO VOLTAGE (N or E2)"
10167 ="WARN SHORTED PRIMARY (N or E2)"
10168 ="WARN OPEN PRIMARY (N or E2)"
10169 ="spare (P or F1)"
10170 ="WARN HI VOLTAGE (P or F1)"
10171 ="WARN NO SECONDARY SPK(P or F1)"

10172 ="WARN LO FROM ENGINE (P or F1)"
10173 ="WARN HI FROM ENGINE (P or F1)"
10174 ="WARN LO VOLTAGE (P or F1)"
10175 ="WARN SHORTED PRIMARY (P or F1)"
10176 ="WARN OPEN PRIMARY (P or F1)"
10177 ="spare (R or F2)"
10178 ="WARN HI VOLTAGE (R or F2)"
10179 ="WARN NO SECONDARY SPK(R or F2)"
10180 ="WARN LO FROM ENGINE (R or F2)"
10181 ="WARN HI FROM ENGINE (R or F2)"
10182 ="WARN LO VOLTAGE (R or F2)"
10183 ="WARN SHORTED PRIMARY (R or F2)"
10184 ="WARN OPEN PRIMARY (R or F2)"
10185 ="spare (S or K1)"
10186 ="WARN HI VOLTAGE (S or K1)"
10187 ="WARN NO SECONDARY SPK(S or K1)"
10188 ="WARN LO FROM ENGINE (S or K1)"
10189 ="WARN HI FROM ENGINE (S or K1)"
10190 ="WARN LO VOLTAGE (S or K1)"
10191 ="WARN SHORTED PRIMARY (S or K1)"
10192 ="WARN OPEN PRIMARY (S or K1)"
10193 ="spare (T or K2)"
10194 ="WARN HI VOLTAGE (T or K2)"
10195 ="WARN NO SECONDARY SPK(T or K2)"
10196 ="WARN LO FROM ENGINE (T or K2)"
10197 ="WARN HI FROM ENGINE (T or K2)"
10198 ="WARN LO VOLTAGE (T or K2)"
10199 ="WARN SHORTED PRIMARY (T or K2)"
10200 ="WARN OPEN PRIMARY (T or K2)"
10201 ="spare (U or L1)"
10202 ="WARN HI VOLTAGE (U or L1)"
10203 ="WARN NO SECONDARY SPK(U or L1)"
10204 ="WARN LO FROM ENGINE (U or L1)"
10205 ="WARN HI FROM ENGINE (U or L1)"
10206 ="WARN LO VOLTAGE (U or L1)"
10207 ="WARN SHORTED PRIMARY (U or L1)"
10208 ="WARN OPEN PRIMARY (U or L1)"
10209 ="spare (V or L2)"
10210 ="WARN HI VOLTAGE (V or L2)"
10211 ="WARN NO SECONDARY SPK(V or L2)"
10212 ="WARN LO FROM ENGINE (V or L2)"
10213 ="WARN HI FROM ENGINE (V or L2)"
10214 ="WARN LO VOLTAGE (V or L2)"

10215 ="WARN SHORTED PRIMARY (V or L2)"
10216 ="WARN OPEN PRIMARY (V or L2)"
10217 ="spare (M1)"
10218 ="WARN HI VOLTAGE (M1)"
10219 ="WARN NO SECONDARY SPK(M1)"
10220 ="WARN LO FROM ENGINE (M1)"
10221 ="WARN HI FROM ENGINE (M1)"
10222 ="WARN LO VOLTAGE (M1)"
10223 ="WARN SHORTED PRIMARY (M1)"
10224 ="WARN OPEN PRIMARY (M1)"
10225 ="spare (M2)"
10226 ="WARN HI VOLTAGE (M2)"
10227 ="WARN NO SECONDARY SPK(M2)"
10228 ="WARN LO FROM ENGINE (M2)"
10229 ="WARN HI FROM ENGINE (M2)"
10230 ="WARN LO VOLTAGE (M2)"
10231 ="WARN SHORTED PRIMARY (M2)"
10232 ="WARN OPEN PRIMARY (M2)"
10233 ="spare (N1)"
10234 ="WARN HI VOLTAGE (N1)"
10235 ="WARN NO SECONDARY SPK(N1)"
10236 ="WARN LO FROM ENGINE (N1)"
10237 ="WARN HI FROM ENGINE (N1)"
10238 ="WARN LO VOLTAGE (N1)"
10239 ="WARN SHORTED PRIMARY (N1)"
10240 ="WARN OPEN PRIMARY (N1)"
10241 ="spare (N2)"
10242 ="WARN HI VOLTAGE (N2)"
10243 ="WARN NO SECONDARY SPK(N2)"
10244 ="WARN LO FROM ENGINE (N2)"
10245 ="WARN HI FROM ENGINE (N2)"
10246 ="WARN LO VOLTAGE (N2)"
10247 ="WARN SHORTED PRIMARY (N2)"
10248 ="WARN OPEN PRIMARY (N2)"

30001 ="ENGINE RPM 1RPM/BIT "
30002 ="MAX SEEN RPM 10RPM/BIT "
30003 ="OVERSPEED SETTING 10/BIT "
30004 ="FAULT GEAR TEETH "
30005 ="4-20 ANALOG INPUT 0.098ma/bit "
30006 ="COUNTS TO DEGREES SCALER "
30007 ="GLOGAL TIMING DISPLAY VALUE "
30008 ="MANUAL RETARD SETTING "

30009 ="ONESTEP RETARD SETTING "
30010 ="ANALOG RETARD FROM TABLE "
30011 ="RPM RETARD FROM TABLE "
30012 ="SERIAL RETARD FROM REMOTE "
30013 ="MAX INDIVIDUAL OFFSET "
30014 ="STANDARD INDIVIDUAL OFFSET "
30015 ="REFERENCE ANGLE OF RESET PIN "
30016 ="NUMBER OF CYLINDERS "
30017 ="ENGINE AVERAGE DIAG "
30018 ="LO SPARK DIAG THRESHOLD "
30019 ="HI SPARK DIAG THRESHOLD "
30020 ="NO SPARK DIAG THRESHOLD "
30021 ="LO FROM ENGINE THRESHOLD "
30022 ="HI FROM ENGINE THRESHOLD "
30023 ="spare "
30024 ="E2 ENABLE THRESHOLD "
30025 ="E2 DISABLE HYSTERISIS "
30026 ="E3 ENABLE THRESHOLD "
30027 ="E3 DISABLE HYSTERISIS "
30028 ="CYL TIMING OFFSET (A or A1) "
30029 ="CYL TIMING OFFSET (B or A2) "
30030 ="CYL TIMING OFFSET (C or B1) "
30031 ="CYL TIMING OFFSET (D or B2) "
30032 ="CYL TIMING OFFSET (E or C1) "
30033 ="CYL TIMING OFFSET (F or C2) "
30034 ="CYL TIMING OFFSET (K or D1) "
30035 ="CYL TIMING OFFSET (L or D2) "
30036 ="CYL TIMING OFFSET (M or E1) "
30037 ="CYL TIMING OFFSET (N or E2) "
30038 ="CYL TIMING OFFSET (P or F1) "
30039 ="CYL TIMING OFFSET (R or F2) "
30040 ="CYL TIMING OFFSET (S or K1) "
30041 ="CYL TIMING OFFSET (T or K2) "
30042 ="CYL TIMING OFFSET (U or L1) "
30043 ="CYL TIMING OFFSET (V or L2) "
30044 ="CYL TIMING OFFSET (M1) "
30045 ="CYL TIMING OFFSET (M2) "
30046 ="CYL TIMING OFFSET (N1) "
30047 ="CYL TIMING OFFSET (N2) "
30048 ="CAVG (A or A1) "
30049 ="CAVG (B or A2) "
30050 ="CAVG (C or B1) "
30051 ="CAVG (D or B2) "

30052	= "CAVG (E or C1)	"
30053	= "CAVG (F or C2)	"
30054	= "CAVG (K or D1)	"
30055	= "CAVG (L or D2)	"
30056	= "CAVG (M or E1)	"
30057	= "CAVG (N or E2)	"
30058	= "CAVG (P or F1)	"
30059	= "CAVG (R or F2)	"
30060	= "CAVG (S or K1)	"
30061	= "CAVG (T or K2)	"
30062	= "CAVG (U or L1)	"
30063	= "CAVG (V or L2)	"
30064	= "CAVG (M1)	"
30065	= "CAVG (M2)	"
30066	= "CAVG (N1)	"
30067	= "CAVG (N2)	"
30068	= "DIAG OFFSET (A or A1)	"
30069	= "DIAG OFFSET (B or A2)	"
30070	= "DIAG OFFSET (C or B1)	"
30071	= "DIAG OFFSET (D or B2)	"
30072	= "DIAG OFFSET (E or C1)	"
30073	= "DIAG OFFSET (F or C2)	"
30074	= "DIAG OFFSET (K or D1)	"
30075	= "DIAG OFFSET (L or D2)	"
30076	= "DIAG OFFSET (M or E1)	"
30077	= "DIAG OFFSET (N or E2)	"
30078	= "DIAG OFFSET (P or F1)	"
30079	= "DIAG OFFSET (R or F2)	"
30080	= "DIAG OFFSET (S or K1)	"
30081	= "DIAG OFFSET (T or K2)	"
30082	= "DIAG OFFSET (U or L1)	"
30083	= "DIAG OFFSET (V or L2)	"
30084	= "DIAG OFFSET (M1)	"
30085	= "DIAG OFFSET (M2)	"
30086	= "DIAG OFFSET (N1)	"
30087	= "DIAG OFFSET (N2)	"
30253	= "YEAR AS AN INTEGER	"
30254	= "MONTH/DAY AS AN INTEGER	"
30255	= "HOUR/MINUTE AS AN INTEGER	"
30256	= "KEY COMMAND REGISTER	"
40256	= "KEY COMMAND REGISTER	"

2.8 Key Command Definition (40256)

Register 40256 can be written to with a set of specific ignition related actions. This register will only work for single register writes (function code 06). If the CPU-95 Display module is currently executing a key command (either from a previous modbus write or from the keypad), the modbus exception "BUSY" (06) will be returned.

2.8.1 Key Commands

0x01FE Increment global retard
0x02FD Decrement global retard
0x03FC Enable current loop
0x04FB Disable current loop
0x05FA Enable RPM retard
0x06F9 Disable RPM retard
0x07F8 Enable serial retard
0x08F7 Disable serial retard
0x09F6 Enable EEPROM protection
0x0AF5 Disable EEPROM protection
0x0BF4 Increment Energy Setting
0x0CF3 Decrement Energy Setting
0x0DF2 Enable Multistrike
0x0EF1 Disable Multistrike
0x0FF0 Increment Overspeed
0x10EF Decrement Overspeed
0x11EE Increment reset position
0x12ED Decrement reset position
0x13EC Ignition fault reset
0x14EB Ignition alarm acknowledge
0x15EA Save current cylinder offsets to EEPROM
0x16E9 Reset manual offsets to 0 in EEPROM
0x17E8 Begin Test Mode
0x18E7 Abort Test Mode
0x19E6 Increment Test Type
0x1AE5 Decrement Test Type
0x1BE4 Increment onestep retard
0x1CE3 Decrement onestep retard
0x1DE2 Increment ignition idcode
0x1EE1 Decrement ignition idcode
0x1FE0 Increment diagnostic lo spark voltage
0x20DF Decrement diagnostic lo spark voltage
0x21DE Increment diagnostic hi spark voltage
0x22DD Decrement diagnostic hi spark voltage
0x23DC Increment diagnostic no spark voltage
0x24DB Decrement diagnostic no spark voltage

0x25DA Increment diagnostic lo from engine threshold
0x26D9 Decrement diagnostic lo from engine threshold
0x27D8 Increment diagnostic hi from engine threshold
0x28D7 Decrement diagnostic hi from engine threshold
0x2BD4 Increment E2 enable threshold
0x2CD3 Decrement E2 enable threshold
0x2DD2 Increment E2 hysteresis threshold
0x2ED1 Decrement E2 hysteresis threshold
0x2FD0 Increment E3 enable threshold
0x30CF Decrement E3 enable threshold
0x31CE Increment E3 hysteresis threshold
0x32CD Decrement E3 hysteresis threshold
0x33CC Reset diagnostic offsets for all cylinders
0x40BF Increment cylinder timing (A or A1)
0x41BE Increment cylinder timing (B or A2)
0x42BD Increment cylinder timing (C or B1)
0x43BC Increment cylinder timing (D or B2)
0x44BB Increment cylinder timing (E or C1)
0x45BA Increment cylinder timing (F or C2)
0x46B9 Increment cylinder timing (K or D1)
0x47B8 Increment cylinder timing (L or D2)
0x48B7 Increment cylinder timing (M or E1)
0x49B6 Increment cylinder timing (N or E2)
0x4AB5 Increment cylinder timing (P or F1)
0x4BB4 Increment cylinder timing (R or F2)
0x4CB3 Increment cylinder timing (S or K1)
0x4DB2 Increment cylinder timing (T or K2)
0x4EB1 Increment cylinder timing (U or L1)
0x4FB0 Increment cylinder timing (V or L2)
0x50AF Increment cylinder timing (or M1)
0x51AE Increment cylinder timing (or M2)
0x52AD Increment cylinder timing (or N1)
0x53AC Increment cylinder timing (or N2)
0x609F Decrement cylinder timing (A or A1)
0x619E Decrement cylinder timing (B or A2)
0x629D Decrement cylinder timing (C or B1)
0x639C Decrement cylinder timing (D or B2)
0x649B Decrement cylinder timing (E or C1)
0x659A Decrement cylinder timing (F or C2)
0x6699 Decrement cylinder timing (K or D1)
0x6798 Decrement cylinder timing (L or D2)
0x6897 Decrement cylinder timing (M or E1)
0x6996 Decrement cylinder timing (N or E2)

0x6A95 Decrement cylinder timing (P or F1)
0x6B94 Decrement cylinder timing (R or F2)
0x6C93 Decrement cylinder timing (S or K1)
0x6D92 Decrement cylinder timing (T or K2)
0x6E91 Decrement cylinder timing (U or L1)
0x6F90 Decrement cylinder timing (V or L2)
0x708F Decrement cylinder timing (or M1)
0x718E Decrement cylinder timing (or M2)
0x728D Decrement cylinder timing (or N1)
0x738C Decrement cylinder timing (or N2)
0xC03F Increment diagnostic offset (A or A1)
0xC13E Increment diagnostic offset (B or A2)
0xC23D Increment diagnostic offset (C or B1)
0xC33C Increment diagnostic offset (D or B2)
0xC43B Increment diagnostic offset (E or C1)
0xC53A Increment diagnostic offset (F or C2)
0xC639 Increment diagnostic offset (K or D1)
0xC738 Increment diagnostic offset (L or D2)
0xC837 Increment diagnostic offset (M or E1)
0xC936 Increment diagnostic offset (N or E2)
0xCA35 Increment diagnostic offset (P or F1)
0xCB34 Increment diagnostic offset (R or F2)
0xCC33 Increment diagnostic offset (S or K1)
0xCD32 Increment diagnostic offset (T or K2)
0xCE31 Increment diagnostic offset (U or L1)
0xCF30 Increment diagnostic offset (V or L2)
0xD02F Increment diagnostic offset (or M1)
0xD12E Increment diagnostic offset (or M2)
0xD22D Increment diagnostic offset (or N1)
0xD32C Increment diagnostic offset (or N2)
0xE01F Decrement diagnostic offset (A or A1)
0xE11E Decrement diagnostic offset (B or A2)
0xE21D Decrement diagnostic offset (C or B1)
0xE31C Decrement diagnostic offset (D or B2)
0xE41B Decrement diagnostic offset (E or C1)
0xE51A Decrement diagnostic offset (F or C2)
0xE619 Decrement diagnostic offset (K or D1)
0xE718 Decrement diagnostic offset (L or D2)
0xE817 Decrement diagnostic offset (M or E1)
0xE916 Decrement diagnostic offset (N or E2)
0xEA15 Decrement diagnostic offset (P or F1)
0xEB14 Decrement diagnostic offset (R or F2)
0xEC13 Decrement diagnostic offset (S or K1)

0xED12 Decrement diagnostic offset (T or K2)
0xEE11 Decrement diagnostic offset (U or L1)
0xEF10 Decrement diagnostic offset (V or L2)
0xF00F Decrement diagnostic offset (or M1)
0xF10E Decrement diagnostic offset (or M2)
0xF20D Decrement diagnostic offset (or N1)
0xF30C Decrement diagnostic offset (or N2)

3.0 Datalog

3.1 Datalog Overview

The datalogs contain all the information as it is read from the CPU-95 ignition. The datalog capacity is 100. Newer logs are always accessed starting at 1 with the oldest log being 100. A datalog 0 exists and is the most "current" data set from the CPU-95 ignition. The datalog is read by a special modbus function code that is covered in the Modbus section of this document. Datalogging is done at specified intervals and events. Changes in state of the CPU-95 ignition diagnostics or configuration will cause an event to occur. An event is a datalog but it is flagged as an event. Along with the binary data log there is an associated "ASCII Capture". A description of the datalog and ASCII capture can be found at the end of this document. The datalogging datalog sub-system.

3.2 Datalog Setup

The new datalogs added a new menu with 5 sub-menus to the display. The datalog setup menu is found after the "AUX PORT SETUP" menu.

DATALOG SETUP
Next Esc Enter

To enter the datalog setup menus press "ENTER".
To continue to the BARGRAPH menu press "NEXT".
To exit press "ESC".

3.3 Current Date

CURRENT DATE
↑09↓12/2001

To change the current month use the "↑" & "↓" keys.
To proceed to change the current day press "ENTER".
To proceed to the current time menu press "NEXT".
To exit press "ESC".

CURRENT DATE
09↑12↓2001

To change the current day use the "↑" & "↓" keys.
To proceed to change the current year press "ENTER".
To proceed to the current time menu press "NEXT".
To exit press "ESC".

Note:

The CPU-95 Display module does not correct for leap year. A manual adjustment will need to be made at that time.

CURRENT DATE
09/12↑2001↓

To change the current year use the "↑" & "↓" keys.
To proceed to change the current month press "ENTER".
To proceed to the current time menu press "NEXT".
To exit press "ESC".

3.4 Current Time

CURRENT TIME
↑08↓00:00

To change the current hour use the "↑" & "↓" keys.
To proceed to change the current minute press "ENTER".
To proceed to the datalog interval menu press "NEXT".
To exit press "ESC".

CURRENT TIME
08↑00↓00

To change the current minute use the "↑" & "↓" keys.
To proceed to change the current hour press "ENTER".
To proceed to the datalog interval menu press "NEXT".
To exit press "ESC".

Note:

3.5 Datalog Interval

DATALOG INTERVAL
↑↓ 5min.

To change the datalog interval use the "↑" & "↓" keys.

To proceed to the datalog power-up menu press "NEXT".

To exit press "ESC".

The datalog intervals are:

1min., 2min., 5min. 10min., 15min., 30min., 1h., 2h., 4h., 8h., 12h., & 24h.

3.6 Datalog Power-Up

DATALOG POWER-UP
↑ RETAIN/erase ↓

Pressing the "↑" key activates the RETAIN feature. In this mode, the datalogs are preserved.

Pressing the "↓" key activates the ERASE feature. In this mode, the datalogs are cleared on power-up.

To proceed to the log after stop menu press "NEXT".

To exit press "ESC".

3.7 Log After Stop

LOG AFTER STOP?
↑ yes/NO ↓

Pressing the "↑" sets this option to YES. In this mode, datalogging is continuous.

Pressing the "↓" sets this option to NO. In this mode, datalogging is only done when the ignition senses rotation.

To proceed to the track timing menu press "NEXT".

To exit press "ESC".

Note:

Setting this option to NO does not prevent events from being logged.

3.8 Track Timing

TRACK TIMING?
↑ yes/NO ↓

Pressing the "↑" sets this option to YES. In this mode, timing changes generate an event log.
Pressing the "↓" sets this option to NO
log.

To proceed to the current date menu press "NEXT".

To exit press "ESC".

Note:

Setting this option to NO does not prevent timing from being recorded in the datalogs.

3.9 Datalog Content

Byte(s)	Description
0,1	Year, same as modbus 30253
2,3	Month/Day same as modbus 30254
4,5	Hour/Minute same as modbus 30255
6	ASCII Flag 'D' for datalog, 'E' for event
7-38	32bytes (2 lines) of the ignition's user comments
39	Bitfield; Modbus 10049-10056, LSB-MSB respectively
40	Bitfield; Modbus 10001-10008, LSB-MSB respectively
41	Bitfield; Modbus 10041-10048, LSB-MSB respectively
42	Bitfield; Modbus 10057-10064, LSB-MSB respectively
43	Bitfield; Modbus 10073-10080, LSB-MSB respectively
44	Bitfield; Modbus 10009-10016, LSB-MSB respectively
45	Bitfield; Modbus 10065-10072, LSB-MSB respectively
46	Bitfield; Modbus 10017-10024, LSB-MSB respectively
47	Bitfield; Modbus 10025-10032, LSB-MSB respectively
48	Bitfield; Modbus 10033-10040, LSB-MSB respectively
49	Bitfield; Modbus 10081-10088, LSB-MSB respectively
50	Engine Average Diagnostic, Modbus 30017
51-52	spare
53	Ignition ID code
54	Test Type
55-56	RPM, Modbus 30001
57	RPM, 10RPM/bit
58	Max RPM, 10RPM/bit, Modbus 30002
59	Overspeed RPM setting, Modbus 30003
60-61	Actual gear teeth counted
62	spare

63	Number of cylinders
64-65	Fault Gear Teeth, Modbus 30004
66	Diagnostic lo spark voltage, Modbus 30018
67	Diagnostic hi spark voltage, Modbus 30019
68	Diagnostic no spark voltage, Modbus 30020
69	4-20 Analog Input 0.98ma/bit, Modbus 30005
70-71	Counts to degrees sclae, Modbus 30006
72-73	Reference angle of reset pin, Modbus 30015
74-75	Global timing display value, Modbus 30007
76	Manual retard, Modbus 30008
77	Onestep retard, Modbus 30009
78	Analog retard from table, Modbus 30010
79	RPM retard from table, Modbus 30011
80	Serial retard from remote, Modbus 30012
81	Global retard
82	Max individual offset, Modbus 30013
83	Standard individual offset, Modbus 30014
84	Watchdog reset counter
85-104	Cylinder timing offset, Modbus 30028-30047
105	E3 enable threshold, Modbus 30026
106	E3 enable hysteresis, Modbus 30027
107	E2 enable threshold, Modbus 30024
108	E2 enable hysteresis, Modbus 30025
109	spare
110	Hi from engine threshold, Modbus 30022
111	Lo from engine threshold, Modbus 30021
112	Shorted primary threshold
113	Open primary threshold
114-133	Individual diagnostics, Modbus 10089-10248
134-153	Raw cylinder spark numbers
154-173	Cylinder average spark numbers, Modbus 30048-30067
174-193	Individual diagnostic offsets, Modbus 30068-30087
194-250	spare

4.0 BarGraph

4.1 BarGraph Overview

The cylinder spark diagnostic can now be viewed as a bargraph.

4.2 BarGraph Setup

The bargraph added a new menu with 2 sub-menus to the display. The bargraph setup menu is found after the "DATALOG SETUP" menu.

BARGRAPH SETUP
Next Esc Enter

To enter the bargraph setup menus press "ENTER".

To continue back to the MULTISTRIKE menu press "NEXT".

To exit press "ESC".

4.3 BarGraph Low Limit

Sets the low value for the bargraph. The low limit span is from 0 to the LOW SPARK THRESHOLD VOLTAGE

BARGRAPH LIMIT
LOW 100↑↓

To adjust the low limit value use the "↑" & "↓" keys.

To continue to the high "BARGRAPH LIMIT" press "NEXT" or "ENTER"

To exit press "ESC".

4.4 BarGraph High Limit

Sets the high value for the bargraph. The high limit span is from the HIGH SPARK THRESHOLD VOLTAGE to 255

BARGRAPH LIMIT
HIGH 100↑↓


To adjust the high limit value use the "↑" & "↓" keys.

To continue to the low "BARGRAPH LIMIT" press "NEXT" or "ENTER"

To exit press "ESC".

4.5 Viewing the BarGraph

Begin from either the "cylinder spark data screen 'F1'" or the "offset adjustment screen 'F4'" and structured using the instantaneous spark data. The cylinder average data is provided as a reference.



CYL A 110 CAVG
L|||||||H

To view the next cylinder press "F2" or "NEXT"

To view the cylinder spark data press "F1".

To view the cylinder offset adjustments press the "F4".

To exit press "ESC".

5.0 Value Protection Password

5.1 Value Protection Password Overview

The value protection feature can be protected by a password. The password must be configured from the PC terminal software prior to use. If a password is programmed, the password must first be keyed in before value protection can be enabled or disabled. The password is 5 digits composed of "F1" for 1, "F2" for 2, "F3" for 3 & "F4" for 4.

5.2 Protection Lock Screen

The "PROTECTION LOCK" menu will appear ahead of the Value Protection screen if a password has been programmed into the unit. Upon successful entry of the password, the "VALUE PROTECTION" menu will appear.



PROTECTION LOCK
***** Next Esc

To enter the password press "F1", "F2", "F3", or "F4".

To continue back to the "VIEW IGN. SETUP" menu press "NEXT".

To exit press "ESC".

5.3 Protection Lock Invalid Screen

If an incorrect password is entered, this screen will be displayed..



PROTECTION LOCK
INVALID

The display will return to the home screen after 1 second.

6.0 Test Mode Option

6.1 Test Mode Option Overview

The test mode can be removed from the unit during programming from the PC as an option for those who do not want or do not use the "TEST" feature. When this option is enabled, the "RUN TEST MODE" menu that normally appears after the "VIEW IGN. SETUP" is removed and cannot be accessed.